

B Series Kits

B5512 48-point Control Panel




Part number	B5512	B5512E*	B11 (Small)	B10 (Medium)	B430 (PSTN)	B444 (4G LTE)	B915	B920	B930	CX4010	ICP-TR1822-CAN
B5512-C	■			■						■	
B5512-C-CN	■			■							■
B5512-C-920	■			■				■		■	
B5512-CC	■			■		■				■	
B5512-CC-920	■			■		■		■		■	
B5512-CC-930	■			■		■			■	■	
B5512-CP	■			■	■					■	
B5512-CP-920	■			■	■			■		■	
B5512-CP-930	■			■	■				■	■	
B5512-D	■		■							■	
B5512-D-920	■		■					■		■	
B5512-D-930	■		■						■	■	
B5512-DP	■		■		■					■	
B5512-DP-920	■		■		■			■		■	
B5512-DP-930	■		■		■				■	■	
B5512E-DP		■	■		■					■	
B5512E-DP-915		■	■		■		■			■	
B5512E-DC			■			■				■	

* Economy models do not include on-board Ethernet

B Series Kits

B4512 48-point Control Panel




Part number	B4512	B4512E*	B11 (Small)	B10 (Medium)	B430 (PSTN)	B444 (4G LTE)	B915	B920	B930	CX4010	ICP-TR1822-CAN
B4512-C	■			■						■	
B4512-C-920	■			■				■		■	
B4512-C-930	■			■					■	■	
B4512-CC	■			■		■				■	
B4512-CC-920	■			■		■		■		■	
B4512-CP	■			■	■					■	
B4512-CP-920	■			■	■			■		■	
B4512-CP-930	■			■	■				■	■	
B4512-D	■		■							■	
B4512-D-CN	■		■								■
B4512-D-920	■		■					■		■	
B4512-D-930	■		■						■	■	
B4512-DP	■		■		■					■	
B4512-DP-920	■		■		■			■		■	
B4512-DP-930	■		■		■				■	■	
B4512E-DC		■	■			■				■	
B4512E-DP		■	■		■					■	
B4512E-DP-915		■	■		■		■			■	

* Economy models do not include on-board Ethernet

B Series Kits

B3512 48-point Control Panel



Part number	B3512	B3512E*	B11 (Small)	B10 (Medium)	B430 (PSTN)	B444 (4G LTE)	B915	B920	B930	CX4010	ICP-TR1822-CAN
B3512-DC	■		■			■				■	
B3512-DC-920	■		■			■		■		■	
B3512-DP	■		■		■					■	
B3512-DP-CN	■		■		■						■
B3512-DP-920	■		■		■			■		■	
B3512-DP-920-CN	■		■		■			■			■
B3512E-DC		■	■			■				■	
B3512E-DP		■	■		■					■	
B3512E-DP-915		■	■		■		■			■	

* Economy models do not include on-board Ethernet