

BVMS Lite 12.1



BVMS Lite is a unique IP video security solution that provides seamless management of digital video, audio, and data across any IP network. It provides the best video management system to go with Bosch video surveillance devices, leveraging the unique capabilities of Bosch cameras and recording solutions. It nevertheless offers interfaces and standards to integrate other systems and manufacturers.

The software is provided as an e-license via e-mail.

Regulatory information

General Data Protection Regulation

The General Data Protection Regulation (GDPR) is enforced on the 25th of May 2018. As a regulation it will be directly applicable to all EU member states without the need for national implementing legislation. As information captured, processed and stored by video surveillance systems is classified as "sensitive" the GDPR will cause significant impact on the video surveillance installations throughout

BVMS includes the required functionality to ensure an organization can be GDPR compliant.









- ▶ Embedded resilience keep operations up and running even when multiple system components fail.
- ▶ Bosch video at its best the best userexperience combining Bosch cameras with BVMS.
- ► Integration integrate third-party cameras, storage and further systems into BVMS.
- ► IT environments and data security benefit from full IT compatibility from installation to day-to-day management in a secure way.
- ▶ Free of charge up to 8 cameras load the license, and off you go.

Installation/configuration notes

Disclaimer

This Software is not designed, intended, or authorized for use in any type of system or application in which the failure of the Software could lead to a risk to health and safety. The user is responsible to verify that the Software and its specified functionalities are suitable for the intended application, in particular with respect to accuracy, safety and security.

The BVMS system design guide is published on the following website:

Bosch Building Technologies Knowledge Base.

The system design guide summarizes the BVMS design details, and serves as a guide to planning a BVMS system with Bosch cameras and storage. It focuses on BVMS combined with the VRM.

To get started, read the following article on the Bosch Security & Safety community website: BVMS - Quick start overview

BVMS Enterprise

Multiple BVMS Lite, Plus, Professional or DIVAR IP systems can be combined into one BVMS Enterprise System.

Video - BVMS Lite 12.1 2 | 5

Cameras within system context	200000
Cameras per operator	10000
Sub-systems	Between 10 sub-systems with 1000 cameras per system or 100 sub-systems with 100 cameras per system.

Software assurance

The complexity of security systems has increased significantly over the last couple of years. At the same time, you are still relying on your system to mitigate security risks. With Bosch Software Assurance, you can relax knowing you can always approach us for help to ensure your system keeps on running. You can find the terms and conditions of Bosch Software Assurance on the following website: About Bosch Software Assurance

Note: BVMS Lite is not covered with Assurance GO. In order to receive professional support, please order Assurance PRO separately.

Technical specifications

The release notes give a detailed overview on the changes that are implemented, compared to the previous BVMS version.

The architects and engineering specifications specify in detail what the system is capable of.

Both documents can be found on the following web page:

Bosch Building Technologies Knowledge Base

System limits



Notice

The system limits are based on the hardware recommendations.

Maximum number of workstations 5 Maximum number of cameras 42 Maximum number of intrusion panels 5 Maximum number of DVRs 10 Maximum number of VRMs 2 Maximum number of sustained events (logbook) / sec 500 Maximum number of sustained events (without logbook) / sec 5000 Maximum peak event load / sec (within 60 minutes) 500 Maximum number of events / sec from ONVIF cameras 500		
Maximum number of intrusion panels Maximum number of DVRs 10 Maximum number of VRMs 2 Maximum number of sustained events (logbook) / sec Maximum number of sustained events (without logbook) / sec Maximum peak event load / sec (within 60 minutes) Maximum number of events / sec 500	Maximum number of workstations	5
els Maximum number of DVRs 10 Maximum number of VRMs 2 Maximum number of sustained events (logbook) / sec Maximum number of sustained events (without logbook) / sec Maximum peak event load / sec (within 60 minutes) Maximum number of events / sec 500	Maximum number of cameras	42
Maximum number of VRMs 2 Maximum number of sustained events (logbook) / sec Maximum number of sustained events (without logbook) / sec Maximum peak event load / sec (within 60 minutes) Maximum number of events / sec 500		5
Maximum number of sustained events (logbook) / sec Maximum number of sustained events (without logbook) / sec Maximum peak event load / sec (within 60 minutes) Maximum number of events / sec 500	Maximum number of DVRs	10
events (logbook) / sec Maximum number of sustained events (without logbook) / sec Maximum peak event load / sec (within 60 minutes) Maximum number of events / sec 500	Maximum number of VRMs	2
events (without logbook) / sec Maximum peak event load / sec (within 60 minutes) Maximum number of events / sec 500		500
(within 60 minutes) Maximum number of events / sec 500		2500
•		5000
	•	500

Logbook size	4GB
--------------	-----



(i) Notice

The logbook size can be increased by upgrading the Microsoft SQL Server Express edition included in the BVMS installation package.

Languages

Component	Languages
Quick installation guide	English, French, German, Simplified Chinese and Spanish
Configuration manual	English, German, Dutch, Italian, Portuguese, Finnish, French, Spanish, Simplified Chinese, Traditional Chinese, Russian, Czech, Greek, Polish, Swedish, Latvian, Lithuanian, Turkish and Korean
Operation manual	English, German, Dutch, Italian, Portuguese, Finnish, French, Spanish, Simplified Chinese, Traditional Chinese, Russian, Czech, Greek, Polish, Swedish, Latvian, Lithuanian, Turkish and Korean
Software	English, German, Dutch, Italian, Portuguese, French, Spanish, Simplified Chinese, Traditional Chinese, Russian, Hungarian, Japanese, Czech, Danish, Finnish, Greek, Norwegian, Polish, Swedish, Thai, Turkish, Korean, Arabic, Ukrainian and Vietnamese

Hardware recommendations

Cameras

All Bosch cameras can be used under the device compatibility concept, which you can find on the Bosch Security and Safety Community in the following article:

How-to: BVMS - Device compatibility

BVMS is an ONVIF Profile S certified video management system.

Management Server, Video Streaming Gateway, Video Recording Manager, and Mobile Video Service

It is recommended to run the Video Recording Manager and the BVMS Management Server on the same computer. Video - BVMS Lite 12.1

The recommended specifications for BVMS Lite are based on the Bosch DIVAR IP AiO 5000.

Item	Description
Operating System	Windows Server 2016 (64-bit)
	Windows Server 2019 (64-bit)
	Windows Server 2022 (64-bit)
	Windows 10 Professional (64-bit) (22H2)*
	Windows 10 Enterprise (64-bit) LTSC (21H2)*
	Windows 11 Pro (64-bit) (22H2)*
СРИ	Intel i3-8100
RAM	8GB
Free disk space	30GB (+ 15% of the hard-drive after installation)
Network	1 Gigabit/s network interface card

^{*} Windows 10 and Windows 11 are not supported for the Video Recording Manager.

Operator Client

Item	Description
Operating System	Windows 10 Professional (64-bit) (22H2)
	Windows 10 Enterprise (64-bit) LTSC (21H2)
	Windows 11 Pro (64-bit) (22H2)
CPU	Intel Xeon W-2123 (3.6 GHz)
RAM	8GB
Free disk space	Minimum 10GB for Single Site Systems
	Minimum 15GB for Enterprise Systems
Network	1 Gigabit/s network interface card
Display resolution	Minimum: 1280 x 1024
	Maximum: 3840 x 2160
Graphic card	Nvidia Quadro P620
	Nvidia Quadro P2000
	Nvidia Quadro P4000
	Nvidia Quadro RTX A2000
	Nvidia Quadro RTX 4000
	Nvidia Quadro P2200
	Nvidia Quadro T600
	Nvidia Quadro T1000
	Intel HD Graphics 630

Network

To achieve the performance listed in the table below, a 1 Gigabit/s network is a minimum requirement between the Operator Client and Management Server.

(Unicast) Maximum number of workstations simultaneously viewing the same camera	5
(Multicast) Maximum number of workstations simultaneously viewing the same camera	100
Event response time (assuming sufficient network performance considering bandwidth and delay)	< 1 second
Alarm visibility time (assuming sufficient network performance considering bandwidth and delay), including 1 live image pane, 1 instant playback image page, and 1 map image pane.	< 2 seconds

(i)

Notice

When the system does not have enough network resources, or is experiencing a temporary decrease in network performance, the event response time and alarm visibility time may increase.

(i)

Notice

The list of communication channels and required network ports can be found in the BVMS Configuration manual.

Storage devices

The storage quick selection guide, which also includes non-Bosch storage devices, can be found on:

http://www.boschsecurity.com/bvms

Device	Series
Bosch DIVAR IP	2000, 3000, 5000, 6000, 7000
Bosch DIVAR IP AiO	4000, 5000, 6000, 7000
Bosch DSA E-Series	2300, 2400, 2500, 2600, 2700, 2800
Bosch DIVAR AN	3000, 5000
Bosch DIVAR network	2000, 3000, 5000
Bosch DIVAR hybrid	3000, 5000
Other hardware	

Туре	Device	Remarks
Decoder	Bosch VIDEOJET de- coder 3000	n/a

Video - BVMS Lite 12.1 4 | 5

Туре	Device	Remarks	Туре	Device
Decoder	Bosch VIDEOJET de- coder 7000	n/a		Tattile Vega 11 Tattile Vega 33
Decoder	Bosch VIDEOJET de- coder 8000	Supports displaying of 4K cameras		
Decoder	Bosch VIDEOJET de- coder 7513	n/a	Ordering in	
Decoder	Bosch VIDEOJET decoder 7523	n/a	Includes 8 c expansions,	icense Lite base amera/decoder e 8 failover recordi nannels, 2 keyboa
Foyer card reader Serial input	MINITER 485 Werner Electronic	n/a n/a	ATM/POS, a	lannets, 2 keyboa llegiant and OPC er MBV-BLIT
Intrusion panel	DTP3N Bosch G-series B9512G 3.03.14,	Automation Device in	Expansion li	NLIT License Cam cense for 1 encod
	Bosch B5812G	the intrusion panels must be configured as Mode 2	Order numb	xact number requ
3.03.14, Bosch B5512 3.03.14,	Bosch B5512		Expansion li workstation	LIT License Work cense for 1 works requires 1 licens er MBV-XWSTLIT
	Bosch B4512 3.03.14, Bosch B3512		MBV-FMAPI Expansion li	LIT License online icense for online iter MBV-FMAPLIT
	3.03.14, Bosch B6512 3.03.14		MBV-FOBJL	IT License Map-b cense for Map-ba
Intrusion panel	Bosch D9412GV4 2.03.018,	Microsoft Windows Patch 3155464 should not be installed	Order numb	er MBV-FOBJLIT
	Bosch D7412GV4 2.03.018		expansion Expansion li	cense for 1 encod
Monitor wall	Barco Transform N	RCPPlus agent 0.9.5.0		er MBV-XDURLIT
Analog matrix switch	Bosch Allegiant Series	Firmware 8.75 or later, Master control soft- ware 2.94	Expansion li required.	IT License DVR estate for 1 DVR.
ATM/POS Bridge	Bosch ATM/POS Bridge	Version 1.10.00.12	MBV-XFOVL expansion	IT License VRM I
Keyboard	Bosch KBD-Universal XF	USB	Failover VRN	cense for 1 encod M. er MBV-XFOVLIT
Keyboard	Bosch Intuikey	Serial, firmware 1.96		T License Intrusi
Digital I/O	Advantech ADAM-6050,	n/a	Expansion li	cense to integrate er MBV-XINTLIT
	Advantech ADAM-6052,		Expansion li	LIT License Keybo cense for 1 CCTV
	Advantech ADAM-6060,			er MBV-XKBDLIT
USB to serial	Advantech ADAM-6066 Belkin serial adapter	n/a	Expansion li exact numbe	
OOD to seliai	F5U103VEA	τη α		er MBV-XLPRLIT LIT License Unma
Ethernet to serial	Comtrol DeviceMaster RTS 4-port	n/a	Expansion li required.	cense for 1 site. (
LPR camera	Tattile Vega Basic Tattile Vega Smart	n/a	Order numb	er MBV-XSITELIT
	Tattile Vega1			

Туре	Device	Remarks
	Tattile Vega 11	
	Tattile Vega 33	

expansions, 2 workstation ding channels, 8 dualard expansions, 1 DVR, and C functionality.

mera/decoder expansion

der/decoder channel. uired.

LIT

kstation expansion

station (each extra se).

ne map functionality

map functionality.

based tracking assistant

ased tracking assistant.

era dual recording

oder channel used for dual

expansion

Order the exact number

Failover channel

der channel used with a

sion panel expansion

te intrusion panels.

oard expansion

V keyboard. Order the

camera expansion

tile) LPR camera. Order the

anaged site expansion

Order the exact number

Video - BVMS Lite 12.1 5 | 5

expansion license.

license

Order number MBV-MDVRLIT

Order number MBV-MPRILIT

Recording VRM expansion license. Order number **MBV-MDURLIT**

MBV-XSUBLIT License Subsystem expansion

Expansion license for 1 subsystem. Order the exact number required.

Order number MBV-XSUBLIT

MBV-FPRILIT License Privacy overlay

Expansion license for Privacy overlay.

Order number MBV-FPRILIT

Software Options

MBV-MLIT SMA license for MBV-BLIT, 1 year

One year of maintenance cover for the BVMS Lite base license.

Order number MBV-MLIT

MBV-MCHANLIT SMA license for MBV-XCHANLIT, 1 year

One year of maintenance cover for the BVMS Lite camera/decoder channel expansion license.

Order number MBV-MCHANLIT

MBV-MWSTLIT SMA license for MBV-XWSTLIT, 1 year

One year of maintenance cover for a BVMS Lite Workstation expansion license.

Order number MBV-MWSTLIT

MBV-MMAPLIT SMA license for MBV-FMAPLIT, 1 year

One year of maintenance cover for an online map functionality license.

Order number MBV-MMAPLIT

MBV-MOBJLIT SMA license for MBV-FOBJLIT, 1 year

One year of maintenance cover for the Map-based tracking assistant license.

Order number MBV-MOBJLIT

MBV-MLIT-DIP SMA license for MBV-BLIT-DIP, 1 year

One year of maintenance cover for the BVMS license for DIVAR IP all-in-one 4000 / DIVAR IP all-in-one 5000.

Order number MBV-MLIT-DIP

MBV-MFOVLIT SMA license for MBV-XFOVLIT, 1 year

One year of maintenance cover for a BVMS Lite Failover VRM expansion license.

Order number MBV-MFOVLIT

MBV-MINTLIT SMA license for MBV-XINTLIT, 1 year

One year of maintenance cover for a BVMS Lite intrusion panel expansion license.

Order number MBV-MINTLIT

MBV-MKBDLIT SMA license for MBV-XKBDLIT, 1 year

One year of maintenance cover for a BVMS Lite CCTV keyboard expansion license.

Order number MBV-MKBDLIT

MBV-MLPRLIT SMA license for MBV-XLPRLIT, 1 year

1 year of maintenance cover for the (Tattile) LPR camera expansion license.

Order number **MBV-MLPRLIT**

Represented by:

Europe, Middle East, Africa:Bosch Security Systems B.V. P.O. Box 80002 5600 JB Eindhoven, The Netherlands Phone: + 31 40 2577 284

www.boschsecurity.com/xc/en/contact/ www.boschsecurity.com

Germany:

Bosch Sicherheitssysteme GmbH Robert-Bosch-Ring 5 85630 Grasbrunn Tel.: +49 (0)89 6290 0 Fax:+49 (0)89 6290 1020 de.securitysystems@bosch.com www.boschsecurity.com

North America

Bosch Security Systems, LLC 130 Perinton Parkway Fairport, New York, 14450, USA Phone: +1 800 289 0096 Fax: +1 585 223 9180 onlinehelp@us.bosch.com www.boschsecurity.com

Asia-Pacific:

MBV-MDVRLIT SMA license for MBV-XDVRLIT, 1 year

One year of maintenance cover for the BVMS Lite DVR

MBV-MDURLIT SMA license for MBV-XDURLIT, 1 year

One year of maintenance cover for a BVMS Lite Dual

MBV-MPRILIT SMA license for MBV-FPRILIT, 1 year

One year of maintenance cover for a Privacy overlay

Robert Bosch (SEA) Pte Ltd, Security Systems 11 Bishan Street 21 Singapore 573943 Phone: +65 6571 2808 Fax: +65 6571 2899 www.boschsecurity.com/xc/en/contact/ www.boschsecurity.com