
CSP-D00114 | Orientation sheet for DCNM-FVP

en Quick installation guide


BOSCH

How to attach the orientation sheet:


1. Remove the protection foil from DCNM-FVP.



- 2. Use cleaning wipes with up to 90% isopropyl alcohol to clean the surface of the voting panel.
- 3. Make sure the surface of the voting panel is free of dust and grease.




- 4. Remove the protective layer from the orientation sheet.
- 5. Gently apply the sheet from left to right (or vice versa) on the surface of the DCNM-FVP while pushing out any excessive air.





How to vote:

Latin Braille script numbers (1 - 5) are used to identify the voting buttons.



Use this button to vote for.

Use this button to vote against.

○ ○ ○ × Use this button to abstain.

Use this button if do not wish to participate in the voting.