




# Cables



## Functions

There are various types of cables and cable sets available for connecting the central components:

Cable set	Connection from ...	... to
CPR 0001 A	MPC Panel Controller	RLE 0000 A Junction Board EU/RLU 0000 A Junction Board US
CRP 0000 A	MPC Panel Controller	MPC Panel Controller (redundant)
CBB 0000 A <sup>1)</sup>	BCM-0000-B Battery Controller Module	Battery pair
CPB 0000 A	BCM-0000-B Battery controller module	UPS Power Supply
CPP 0000 A	HPD 0000 A Power Distributor	UPS Power Supply
PDC 0000 A <sup>1)</sup>	HPD 0000 A Power Distributor	BCM-0000-B Battery Controller Module and battery pair
CPA 0000 A	MPC Panel Controller / ENO 0000 B Fire Service Interface Module	AT 2000 Transmission Unit

*1) Required if the power supply is in a separate Power Supply Housing*

Cable sets CBB 0000 A and PDC 0000 A are required if the power supply is located in a separate Power Supply Housing. These sets have a longer connection cable to the battery than the standard cable sets supplied with the unit.

## Ordering Information

<b>CPR 0001 A Printer Cable</b> used to connect the MPC Panel Controller and a Junction Board, cable length 100 cm	<b>CPR 0001 A</b>
<b>CRP 0000 A Cable Set Redundant Panel Controller</b> used to redundantly connect one Panel Controller to an additional MPC Panel Controller	<b>CRP 0000 A</b>
<b>CBB 0000 A Cable Set BCM/Battery</b> Used to connect a battery pair and a Power Supply Housing to the BCM-0000-B Battery Controller Module	<b>CBB 0000 A</b>
<b>CPB 0000 A Cable BCM/UPS</b> Used to connect the BCM-0000-B Battery Controller Module to a UPS Power Supply, cable length 150 cm	<b>CPB 0000 A</b>
<b>CPP 0000 A Cable HPD/UPS</b> Used to connect an HPD 0000 A Power Distributor to a UPS Power Supply, cable length 120 cm	<b>CPP 0000 A</b>

**Ordering Information**

**PDC 0000 A Cable Set HPD/BCM/Battery**      **PDC 0000 A**  
with 3 connection cables: HPD/BCM, bat-  
tery/battery, HPD/battery

**CPA 0000 A Cable Set AT 2000**      **CPA 0000 A**  
Used to connect an AT 2000 to the MPC and  
the ENO 0000 B.

**Americas:**  
Bosch Security Systems, Inc.  
130 Perinton Parkway  
Fairport, New York, 14450, USA  
Phone: +1 800 289 0096  
Fax: +1 585 223 9180  
security.sales@us.bosch.com  
www.boschsecurity.us

**Europe, Middle East, Africa:**  
Bosch Security Systems B.V.  
P.O. Box 80002  
5600 JB Eindhoven, The Netherlands  
Phone: + 31 40 2577 284  
Fax: +31 40 2577 330  
emea.securitysystems@bosch.com  
www.boschsecurity.com

**Asia-Pacific:**  
Robert Bosch (SEA) Pte Ltd, Security Systems  
11 Bishan Street 21  
Singapore 573943  
Phone: +65 6258 5511  
Fax: +65 6571 2698  
apr.securitysystems@bosch.com  
www.boschsecurity.com

**Represented by**