

# Learn Mode Freeze Sensor

www.boschsecurity.com



**BOSCH**  
Invented for life



- ▶ Use when temperature can drop below 0°C (+32°F)
- ▶ Sends restore signal when temperature increases to +13°C to +15°C (+55°F to +60°F)

The Learn Mode Freeze Sensor detects low temperatures that can cause pipes to freeze or burst. It is ideal for detecting furnace failure in cold climates.

## Functions

### Learn Mode Technology

Each device has a unique, programmed identity. Control panels recognize and learn the identity of each device in the system, eliminating programming errors in the field.

## Installation/configuration notes

### Compatibility Information

Receivers: RF3226 Quik Bridge Receiver  
 Quik Bridge Learn Mode Loop Receiver  
 (P/N: 60-660-01-95R)

Expanders: D208RF Receiver Expander  
 D216RF Receiver Expander

## Parts included

Quantity	Component
1	Sensor housing

1	Hardware pack
1	Literature pack

## Technical specifications

### Electrical

Battery:	3.6 VDC (½ AA) lithium battery (P/N: 34-026)
Battery Life:	5 to 8 years

### Mechanical

Color:	White
Dimensions:	12.4 cm x 4.0 cm x 2.4 cm (4.88 in. x 1.56 in. x 0.94 in.)
Radio Frequency:	319.5 MHz
Bandwidth:	24 kHz

## Ordering information

### Learn Mode Freeze Sensor

Detects low temperatures that can cause pipes to freeze or burst

Order number **60-504-10-3195**

---

**Accessories**

**Shock or Freeze Sensor Case (White)**

Empty plastic case for replacing damaged or blemished freeze or shock sensor cases

Order number **60-267**

---

**Shock or Freeze Sensor Case (Brown)**

Empty plastic case for replacing damaged or blemished freeze or shock sensor cases

Order number **60-268**

---

**Radio Frequency Sniffer**

Emits a series of beeps when RF transmission is detected

Order number **60-401**

---

**Represented by:**

**Americas:**

Bosch Security Systems, Inc.  
130 Perinton Parkway  
Fairport, New York, 14450, USA  
Phone: +1 800 289 0096  
Fax: +1 585 223 9180  
security.sales@us.bosch.com  
www.boschsecurity.us

**Europe, Middle East, Africa:**

Bosch Security Systems B.V.  
P.O. Box 80002  
5617 BA Eindhoven, The Netherlands  
Phone: + 31 40 2577 284  
Fax: +31 40 2577 330  
emea.securitysystems@bosch.com  
www.boschsecurity.com

**Asia-Pacific:**

Robert Bosch (SEA) Pte Ltd, Security Systems  
11 Bishan Street 21  
Singapore 573943  
Phone: +65 6571 2808  
Fax: +65 6571 2699  
apr.securitysystems@bosch.com  
www.boschsecurity.asia

**China:**

Bosch (Shanghai) Security Systems Ltd.  
201 Building, No. 333 Fuquan Road  
North IBP  
Changning District, Shanghai  
200335 China  
Phone +86 21 22181111  
Fax: +86 21 22182398  
www.boschsecurity.com.cn

**America Latina:**

Robert Bosch Ltda Security Systems Division  
Via Anhanguera, Km 98  
CEP 13065-900  
Campinas, Sao Paulo, Brazil  
Phone: +55 19 2103 2860  
Fax: +55 19 2103 2862  
latam.boschsecurity@bosch.com  
www.boschsecurity.com