

# Technical Bulletin

## Fire Drill not following programmed duration on a G Series Panel



**BOSCH**

Invented for life

### Issue severity

- High. Act immediately
- Medium. Bosch Security Systems strongly recommends you take the action described below.
- Low. Advisory

### Products affected

► B8512G, B9512G (v3.08.xx, v3.09.xx)

**January 08th, 2020**

#### Issue

When using the Fire Drill button on a B925F or B926F keypad, the Fire Drill will not follow the programmed Fire Drill Duration parameter.

#### Resolution

The Fire Drill will only flash and not keep sounding, to sound the Fire Bell you will need to manually activate the sounders.

This will be resolved in v3.10.xx

**Bosch Security Systems B.V.**

Torenallee 49

5617 BA Eindhoven

Netherlands

[www.boschsecurity.com](http://www.boschsecurity.com)

© Bosch Security Systems B.V., 2020