D2212B and D2212BE Overview

Input/Points

FA422 for Inovonics RF (D2212B and D2412U only)

D285 Smoke Detector 12-24 VDC, 2-wire (2-wire base required)

D208 Point Expander (D2212B or D2412U only)

D133 Relay Module (up to 2) or D134 Dual Relay Modules

D208RF or D216RF Point Expander and ITI Learn Mode Sensors (D2212B or D2412U only)

Communications

Compatible with SAFECOM® Radio Communicators: SC2104, SC3100, & SC4000

D160 Single Modular Phone Cord

D166 RJ31X Phone Jack

C900V2 Dialer Capture Module

D5200CE Programmer

Remote Programming Software (RPS)

Accessories

D101 Lock and Key Set

Modules & Power

D1625 Transformer (D2212BE, D2412UE) D1640 Transformer (D2212B, D2412U)

D1250 Battery 12 V, 5 Ah

D126 Battery 12 V, 7 Ah

Keypads

Up to 8 Keypads: D220A, D222A, & D223A Programmable from D222A or D223AKeypads