

Parallel Printer Interface Module D9131A

User's Guide



1.0 Overview

1.1 Description

The printer installed with your security system records various types of events. You need a D9131A Parallel Printer Interface Module to be able to use the printer. Your security system has been programmed by your security technician to provide you with printed reports of activities such as Openings, Closings, Alarms, etc. This User's Guide describes the types of reports that can be printed, and explains the information contained in these reports. The manual that comes with your printer explains printer functions such as how to load printer paper.

You can display events from your security system on a monitor; however, you will not retain a permanent record of your system events this way.

1.2 Operation

The security system only remembers a certain number of events. If more than this number of events occur, new events push out older events one by one. Your system has a *Print Log* command that allows you to print the entire history of events stored in your system or you may select to print only events that have occurred from a specific date forward.

1.3 Printing Format

Your security system prints events with top and bottom margins and form feed between pages with descriptive headers. Each event is printed on two lines. The first line contains the time and date the event occurred. The second line contains the type of event and additional information.

EVENT	ACCT	AR	ID	PT#	TEXT
01/01 01:21AM					
Fire Alarm	1111	1		1	Hall Smoke
01/01 01:22AM					
Fire Cancel	1111	1	002	1	John Smith
01/01 01:23AM					
Fire Restoral	1111	1		1	Hall Smoke

Line 1:

- Date the event occurred at the panel
- Time the event occurred at the panel

Line 2:

- Event Description

Indicates the current armed status. The descriptions are listed alphabetically under Section 2.0 *Event Descriptions and Troubleshooting* beginning on page 5.

- Account Number
- Area Number
- ID Number

USER XXX Event reported was initiated by this user ID.

USER XXX-0 Event reported was initiated with the Master User (Card/Token).

USER XXX-1, 2, 3 Event reported was initiated with the Sub User Noted (Card/Token).

- Point Number

D9131A

Overview

- Text

Usually this is programmed by your alarm technician, however, the following text is not:

SDI XX- Event reported was initiated by the Serial Device Interface indicated. The numbers 1 through 8 indicate the event is from one of the supervised command centers. The numbers 17, 18 or 19 indicate the event is from a printer. Numbers 33 to 40 indicate the event is from the Access Control Module.

(The following text indicates previous armed status.)

Was Master Armed

Was Perim Delay

Was Perim Instant

Was Disarmed

Was Mstr Instnt

- User Text

Your alarm technician usually will program this. User text is printed whenever an event with a User ID is noted.

Event Description and Troubleshooting

2.0 Event Descriptions and Troubleshooting

The following events and their respective descriptions are listed in alphabetical order. Your system may not display all of the events. For detail in the cause of events, see your *Security System Owner's Manual*.

Event	Description
Access Granted	A card access holder has been granted access at the point specified.
AC Failure	AC power to the security system is interrupted. Check the plug-in transformer and the circuit breaker.
AC Restoral	AC power to the security system has been restored.
ALARM-Door Open	An access door has been held open beyond the allowed time while the area was armed.
Alarm Report	Alarm at device in area specified. This event also reports Cross Point Alarms, including Cross Group (CG:##) information.
All Points Tested	All points have been tested while in the Service Walk Test, Fire Walk Test, or Walk Test mode.
Bad Call To RAM	System tried to call Remote Account To Ram Manager (RAM) and failed. Call your security company.
Battery Low	Security system battery is low. Replace the battery.
Battery Missing	Security system battery is disconnected or has discharged. Reconnect the battery; call for service.
Battery Restore	Security system battery has recharged.
Cancel Alarm	User with reported ID canceled an alarm from the area specified.
Card Assigned	An access card/token was added to the system.
Command Bypass	Device specified is bypassed.* System will not respond to faults at this point.
Closing Early	User armed area earlier than expected.
Closing Late	User armed area later than expected.
Closing Report	User with reported ID armed area.
Comm Failure	Security system could not communicate using the phone number reported. Call for service.
Date Changed	User with reported ID changed the date in the security system.
Door Closed-Restoral	An access door in the area specified restored to normal after a Door Left Open event has occurred.
Door Cycled	An access door in the area specified was cycled.
Door Left Open	The door specified has been left open past the programmed time.
Door Locked	An access door in the area specified was locked for normal operation.
Door Secured	An access door in the area specified was secured, which prohibits access.
Door Unlocked	An access door in the area specified was unlocked allowing free access.
Duress	User with reported ID manually initiated a special alarm in the area specified.
Early to Open	User disarmed area earlier than expected. If the entire security system is being disarmed, the previous state of security system is indicated. If just one area is being disarmed, no previous status is indicated.
Extra Point	Area specified reports an unprogrammed device. Call for service.
Extn Close Time	User with reported ID extended area's closing time to that specified.
Fail To Close	Area failed to arm within your programmed closing window.
Fail To Open	Area failed to disarm within your programmed opening window.
F Close Early	User with reported ID force armed* specified area later than expected.
F Close Late	User with reported ID force armed* specified area later than expected.
F Close Pr Dlay	User with reported ID force armed* perimeter with entry/exit delay.
F Close Pr Inst	User with reported ID force armed* area perimeter with no delay time.
Fire Alarm	Fire Alarm at device specified.
Fire Cancel	See Cancel Alarm.
Fire Restoral	The fire trouble or alarm event at the device specified has been restored.

Event Description and Troubleshooting

Event	Description
Fire Supervision	Supervision condition at the fire point specified.
Fire Supervision Restoral	Supervision condition at the fire point specified has been restored.
Fire Trouble	Trouble condition at area device specified.
Fire Walk End	Walk test* for fire devices in the area specified is complete.
Fire Walk Start	A walk test* is in progress for fire devices in the area specified.
Forced Close	User with reported ID armed area with point(s) faulted.
Forced Point	User force armed device in area reported.
Late To Close	User with reported ID armed the security system later than expected.
Late To Open	User with the reported ID disarmed area later than expected. If the entire security system is being disarmed, the previous state of the system is indicated. If just one area is being disarmed, no previous state is indicated.
Log Overflow	Security system event log is full. Events are being overwritten.
Log Threshold	Security system event log is at the programmed maximum capacity.
Missing Alarm	Device in area specified is not reporting. Call for service.
Missing Fire	Fire device in area specified is not reporting. Call for service.
Missing Trouble	Trouble Condition at area device specified.
Msngr Supervision	Supervision device at area specified is not reporting.
No Entry - Level	An access card holder attempted access but was denied due to the user's authority level.
No Entry - Interlk	Access was denied due to the interlock door being open.
No Entry - Secured	Access was denied due to the door being secured.
No Entry - Unknown	Access was denied because the user was not found in the database.
Opening Report	User with reported ID disarmed area.
Params Changed	Security system programming has been changed.
Peri Dlay Armed	User with ID reported armed the perimeter of the specified area with delay time.
Peri Inst Armed	User with reported ID armed the perimeter of the specified area with no delay time.
Phone Line Fail	The phone line specified is not working. Call for service.
Phone Restoral	The problem with the phone line specified has been restored.
Point Bypass	Area device specified is bypassed.* System will not respond to faults at this device.
Point Closing	User armed device in area specified.
Point Opening	User disarmed device in area specified.
Point Status	Status report for device in area specified.
Point Tested	This device has been walk tested.*
Prog Access Ok	Account has been accessed locally by the device specified.
Pt Bus Trouble	Wiring problem. Call for service.
Pt Bus Restoral	Wiring problem is resolved.
Ram Access Fail	Technician could not access your security system from the security company.
Ram Access Ok	Your security company accessed your system from the security company.
Re-Boot	Your security system was reset.
Relay Reset	Relay has reset.
Relay Set	Relay specified has been turned on.
Request To	A Request To Enter device for an access door has been activated.

Event Description and Troubleshooting

Event	Description
Enter	
Request To Exit	A Request To Exit device for an access door has been activated.
Restoral Report	Restoral at point in area specified.
RF Low Battery	A Low Battery condition at the point specified has been detected.
RF Batt Restor	The Low Battery condition previously sent from the point specified has restored.
RTE Deny Intrlok	A Request To Enter device has been activated but was denied due to the interlock door being open.
RTE Deny Secured	A Request To Enter device has been activated but was denied due to the door being Secured. See Door Secured.
REX Deny Intrlok	A Request To Exit device has been activated but was denied due to the interlock door being open.
REX Deny Secured	A Request To Exit device has been activated but was denied due to the door being Secured. See Door Secured.
S: Alarm	Status report: alarm at area specified.
S: Closing	Status report: closing at area specified.
S: Fire Supervision	Status report: Fire Supervision at area specified.
S: Opening	Status report: opening at area specified.
S: Perim Delay	Status report: area perimeter specified is armed with entry/exit delay.
S: Perim Instant	Status report: area perimeter specified is armed (no delay).
S: Supervision	Status report: Supervision at area specified.
S: Trouble	Status report: trouble at area specified.
SDI Failure	Serial Device Interface specified is not reporting. 1-8 = command centers; 017, 018, 019 = printers; 33-40 = Access Control Module. 80 = Home Automation; 88 = RAMIV/Netcom. Make sure the device is plugged in.
SDI Restoral	The problem with the device specified is resolved.
Sensor Reset	User with reported ID reset detection devices in area specified.
Service End	A Service Walk Test in the specified area has ended.
Service Start	A Service Walk Test in the specified area has started.
Sked Bypass	Sked* in area specified is bypassed.* System will not respond to faults at this device.
Sked Changed	User with reported ID changed the Sked* indicated.
Sked Executed	Sked* was activated.
Status report	Status report was sent to the receiver.
Supervision	Supervision condition at point specified.
Swinger Bypass	Area specified had four alarm or trouble signals within an hour. It is now bypassed from the system.
Test Report	Test report was sent.
Time Changed	User with reported ID changed the time in the security system.

Event Description and Troubleshooting

Event	Description
Trouble Door Open	Access door was left open beyond the programmed time.
Trouble Report Unverified Event	Trouble condition at device specified. The point specified generated an unverified alarm event.
User Alarm Cmd7	User with reported ID manually initiated special alarm in the area specified.
User Alarm Cmd9	User with reported ID manually initiated special alarm in the area specified.
Usr Code Change	User ID specified was changed.
Usr Code Delete	User ID specified was deleted.
User Level Set	The authority level of the specified user has been modified.
User Tamper	User with wrong ID tried to access specified area.
Walk End	Walk test in area specified is complete.
Walk Start	A walk test is in progress in the area specified.
Was Force Armed	User with the reported ID force armed* account with point(s) faulted.
Watch Mode Start	The Watch Mode in the specified area has started.
Watch Mode End	The Watch Mode in the specified area has ended.
Watchdog Reset	Panel was internally reset.

* For an explanation of terms, see your *Security System Owner's Manual*.