

DCNM-FSLP Flush language selection panel DICENTIS



With the elegantly designed DICENTIS Flush language selection panel, participants can conveniently listen to the speaker in their preferred language directly to their headphones. Language selection is straightforward: it is automatically activated when the headphones are connected to the device. The participant can scroll through the available languages by pressing the illuminated touch buttons. If a preferred language for the participant is defined in the system, the language selector automatically uses the defined language. Available languages can be displayed in native characters or as ISO abbreviations. The volume can also be adjusted through the illuminated touch buttons.

The DCNM-FSLP connects through an RJ12 connector to transfer data and to the DCNM-FBD2 headset connector for the audio.

Functions

Display

- · Language selection in original characters.
- Language selection in ISO abbreviation form.
- · Language numbers.
- The display is off when the headphones are not connected.
- The display switches off automatically after not using any buttons for approximately 8 seconds, to minimize distractions from the meeting.

Headphones

 The panel allows you to control the headphones' volume so the interpretations or floor can be heard clearly even when there is excessive background noise.

- ► Also available in customized colors, wood, stone or metal designs
- ► Supports up to 100 languages
- ▶ Indication of the native character language
- Automatic language selection
- Screen turns off to save energy and avoid distraction

• To prevent acoustical feedback, the volume control is automatically reduced when the participant is speaking.

Controls and indicators

- 1.44-inch display with 4 touch buttons.
- · The LED indicators on the device show:
 - Left side: Headphone volume control.
 - Right side: Language selector.

Interconnections

- Control interface, through RJ12, to the DCNM-FBD2 and other devices.
- Connects to a DCNM-FBD2 through a CAN connection and through the headphone connection for the audio.
 - The DCNM-FBD2 supports one DCNM-FSLP per side.
- One 3.5 mm (0.14 in) headphone sockets stereo jack type.
- Connector for external headphones through soldering or through a connector.

Parts included

Quantity	Component	
1	DCNM-FSLP Flush language selection panel	
1	30 cm cable	
1	Headphone connection cable	

Technical specifications

Technical specifications			
Audio			
Frequency response (-3 dB) (Hz)	100 Hz – 20,000 Hz		
Total harmonic distortion + noise (%)	0.10%		
Dynamic range (dB)	90 dB		
Minimum signal-to-noise ratio (dB)	90 dB		
Headphones			
Nominal output level (dBV)	0 dBV		
Maximum output level (dBV)	3 dBV		
Minimum impedance (Ω)	32 Ω		
Maximum output power (mW)	65 mW		
Electrical			
Power consumption (W)	0.50 W		
Operating voltage (VDC)	5 VDC		
User interface			
Display type	LCD		
Display size (in)	1.44 in		
Mechanical			
Mounting type	Click-to-fit in a metal panel with a thickness of 2 mm, or in combination with the DCN-FCOUP Flush coupling and the DCNM-FEC Flush end cap in any surrounding		
Dimensions (H x W x D) (mm)	56 mm x 100 mm x 51 mm		
Dimensions (H x W x D) (in)	2.20 in x 3.94 in x 2.01 in		
Weight (g)	67 g		
Weight (lb)	0.15 lb		
Color (RAL)	RAL 9017 Traffic black		

Environmental

According to IEC 60721: storage (1K3), transportation (2K2) and operational (3K4).

Operating temperature (°C)	5 °C - 45 °C
Operating temperature (°F)	41°F – 113°F
Transportation temperature (°C)	-30 °C – 70 °C
Transportation temperature (°F)	-22 °F – 158 °F
Storage temperature (°C)	-5 °C – 45 °C
Storage temperature (°F)	23°F – 113°F
Operating relative humidity, non- condensing (%)	5% - 90%

Ordering information

DCNM-FSLP Flush language selection panel Flush-mounted language selection panel. Order number **DCNM-FSLP | F.01U.402.927**

Software Options

DCNM-LSSL License for language selector at 1 seat

The DICENTIS Select Language at Seat license enables the language selection feature of the DICENTIS Multimedia and DICENTIS Discussion device with touchscreen. The DICENTIS Discussion device with language selector has the functionality built-in. Order number **DCNM-LSSL | F.01U.300.534**

Services

EWE-DCNMFU-IW 12 mths wrty ext dicentis flush unit 12 months warranty extension Order number **EWE-DCNMFU-IW**

Represented by:

Europe, Middle East, Africa: Bosch Security Systems B.V. P.O. Box 80002 5600 JB Eindhoven, The Netherlands www.boschsecurity.com/xc/en/contact/ www.boschsecurity.com

Germany:
Bosch Sicherheitssysteme GmbH
Robert-Bosch-Platz 1
D-70839 Gerlingen
www.boschsecurity.com

North America: Bosch Security Systems, LLC 130 Perinton Parkway Fairport, New York, 14450, USA www.boschsecurity.com Asia-Pacific:
Robert Bosch (SEA) Pte Ltd, Security Systems
11 Bishan Street 21
Singapore 573943
www.boschsecurity.com/xc/en/contact/
www.boschsecurity.com