

# **B3512 IP control panel, 16 points** B Series



The B3512 Control Panel integrates intrusion and residential fire, providing one simple user interface for both systems. The B3512 provides up to 16 individually identified points in a single area. The control panel communicates via the built-in Ethernet port or via compatible plug-in modules that can send events over the public switched telephone network (PSTN) or over cellular network communications.

With the B3512, you can monitor doors, windows, and motion within areas like showrooms or those that hold inventory. Each user can have a personalized passcode, a wireless keyfob, and an access credential to control the system. Use programmable authority levels with restricted privileges to provide service, security, and cleaning personnel with full or limited access. Use the three programmable outputs to turn on lights or lock and unlock doors. Users can:

- Turn on the system to secure the stock room while you conduct daily business.
- Perform tests to ensure your system is working properly.
- Set your system to alarm immediately if a door opens.
- Activate the Watch feature so a tone sounds whenever a customer enters.

- Provides up to 16 points using 8 on-board and 8 wireless points for installation flexibility with perimeter and interior control. Supports keypad points.
- On-board Ethernet port for Conettix IP alarm communication and remote programming, compatible with modern IP networks including IPv6/IPv4, Auto-IP, and Universal Plug and Play
- Installer-friendly features for simple installation and communications, including plug-in PSTN and cellular communication modules
- Programmable keypad shortcuts, situation sensitive on-screen help, and a bilingual user interface make system operation simple and easy
- Set a schedule for your system to automatically turn on at closing time.
- Use wireless security options to customize your system.

Central monitoring stations provide 24-hour system monitoring with access to vital services. Professional security personnel can test the system, monitor system activity, and alert the police, fire department, or other emergency response teams if necessary.

## Functions

## **Programmable outputs**

- Three programmable on-board outputs; one high current using a relay, and two trigger outputs
- Output A, with a contact rating of 3 Amps, can supply up to 1.0 A total current from AUX PWR
- Outputs B and C sink up to 50 mA at 12 VDC
- Four alarm-output patterns
- Programmable bell test

## **Output Profiles**

Output Profiles support custom programming and provide a way for outputs to operate based on unique application requirements.

Once an Output Profile is created, it can be reused and assigned to multiple outputs enabling quick output programming. You can create Output Profiles that define how an output operates when specific events occur. Output Profiles provide a way to assign and use consistent output effects throughout the system.

### System response

- High-performance micro-controller provides industry leading system response
- 20 custom point profiles
- Selectable point response time
- Cross point capability
- Fire alarm verification
- Dangerous gas indicator includes carbon monoxide (NFPA 720)
- Watch mode
- A scheduled event (SKED) to perform several functions, such as turn on (arm) the system, turn off (disarm) the system, bypass and unbypass points, and control relays

## **User interface**

- Supervision of up to 4 keypads
- Custom keypad text is fully programmable through RPS
- Full function menu including custom functions
- Authority by area and 32 character name for each user
- 14 custom authority levels control user's authority to change, add, or delete passcodes to disarm or bypass areas; and to start system tests
- Programmable primary and secondary language by user and keypad
- 12 available languages (any two can be concurrently used)

## User interface languages

The following table shows the available languages per keypad type.

	B915/ B915i	B920/ B925F/ B926F / B926M	B921C	B930	B940W/ B942/ B942W
English	•	~	~	~	•
Chinese	~				•
Dutch	~	~	~	~	•
French	~	~	~	~	•
German	~	~	~	~	•
Greek	~				•
Hungarian	~	~	~	~	•
Italian	~	~	~	~	•

	B915/ B915i	B920/ B925F/ B926F / B926M	B921C	B930	B940W/ B942/ B942W
Polish	•				~
Portuguese	~	~	~	~	~
Spanish	~	~	~	~	~
Swedish	~	~	~	~	~

## Area Re-Arm

For higher security applications, this feature guarantees that areas are always rearmed, and are disarmed for no longer than a specific, configurable, amount of time (for example, service time).

## **Custom functions**

For added convenience, the installer can program one custom function. A custom function allows customers to complete complex tasks with fewer keystrokes. For example, a custom function can bypass a group of points and arm the system, allowing the user to perform this function with one easy command. Installers can use custom functions to control a particular room. Customers activate a custom function with a keypad, with a keyfob, by faulting a point, or automatically as a scheduled event (SKED).

## **Passcode security**

- Two-man rule. Requires two people with two unique passcodes to be present at the time of opening.
- Early ambush. Allows users to verify that the facility is safe by requiring two passcodes. The control panel sends a duress event if the user does not enter the passcode a second time after inspecting the premises.
- Dual authentication. Requires two forms of identification before processing certain system commands, including turning off the system and opening doors. A standard system user must have a passcode, a credential (token or card), and appropriate command authority permissions.

## Easy exit control

The control panel changes from one On (armed) state to another without turning off (disarming) the system. For example, if you change the state from Part On (Perimeter Arm) to All On (Master Arm), the control panel complies and reports the change. Easy exit control reduces the number of keystrokes, simplifying system operation.

## Programmable passcode-controlled menu list

Passcode-controlled shortcuts provide users only with the options and information pertinent to them, simplifying system operation.

#### Monitor Delay/Delayed Response

Create a special point profile that delays the reaction of a point for a specified time (up to 1 hour in minutes and seconds). This delay provides time for the specified condition to reset before activating any annunciation. The system can annunciate locally and send a report, if desired. When the system is armed, the point can respond like a normal point - providing dual functionality. Use this feature to ensure that perimeter doors have not been propped open, or to monitor critical areas such as computer rooms and safes, for example.

## System users

The system supports up to 10 users. Each user can have a personalized passcode, a wireless keyfob, and an access credential to control the system. You can assign passcodes to one of 14 customized authority levels that can be restricted to operate only during certain times. Programmable primary and secondary language by user and keypad; select from English, Chinese, French, Greek, Hungarian, Italian, Polish, Portuguese, and Spanish.

#### **Route groups and destinations**

The control panel can send reports to four different route groups using one primary and up to three backup destination devices for each route group.

#### **Reporting capabilities**

The control panel has flexible communications for most central station receivers with reporting capabilities such as:

- Individual point numbers
- Opening or closing reports by user and area number
- · Remote programming attempts
- Diagnostic reports

## **Destination test**

It is possible to send test reports to each and all destinations within each route group.

## **Communication formats**

The control panel sends reports in these formats:

- Contact ID (PSTN)
- Modem4 (PSTN)
- Conettix Modem4
- Conettix ANSI-SIA Contact ID
- ANSI-SIA DC-09

# (i) Notice

## UL and ULC LISTED applications

ANSI-SIA DC-09 format is not available for UL and ULC LISTED applications.

# **IP** communication

The control panel can use IP to communicate with a CONETTIX B6800 Central Station Software Receiver, a CONETTIX D6600 or a CONETTIX D6100 IPv6 communications receiver/gateway. Use one of the following for IP:

- The on-board Ethernet connection
- Ethernet Communication Module: B426
- Plug-in cellular communicator: B444-G/B444-A/ B444-V/B444-A2/B444-V2

Conettix IP communication provides a secure path that includes anti-replay/anti-substitution features, and enhanced security with up to AES 256-bit encryption (using Cipher Block Chaining (CBC)). The control panel supports Domain Name System (DNS) for both remote programming and central station communication. DNS provides ease of use, eliminating the need to use static IP addresses as your reporting destination, and accommodates a simple solution for central station disaster recovery. The control panel supports both IPv6 and IPv4 networks.

## **Communication paths**

The control panel accommodates up to four separate phone and four separate network paths to the central station receiver. When resetting alarms or turning a system on and off, the user is identified by name and number.

#### **Personal notification**

The control panel can send text messages and emails for personal notification over Ethernet or using a cellular communicator. You can configure up to 16 destinations using a combination of cellular phone numbers and email addresses. The control panel sends notifications in the user's programmed primary language.

## Firmware updates

Remote firmware updates are available.

#### A wide variety of input options

Each point:

- Accommodates normally-open (NO) and normally-closed (NC) devices with end-of-line (EOL) resistor supervision.
- Accepts programming for fire, gas, fire supervisory, or intrusion applications.
- Supports hardwired and wireless devices.

#### Security and fire detection

The control panel provides 8 on-board points, and up to 8 additional wireless points. You can program individual points to monitor burglar alarms, fire alarms, and supervision devices.

#### Event log

The event log stores local and reported events. The event log includes information such as time, date, event, area, point, and user. View the event log from a keypad or use RPS to remotely retrieve event information. When the event log reaches a programmed threshold of stored events, it can send an optional report to a receiver.

The log stores up to 127 local and reported events.

#### Scheduled events (SKEDs)

The internal clock and calendar start a scheduled event (SKED). A SKED performs functions such as turn on or off, relay control, or point bypassing. The control panel offers:

- One scheduled event with up to 25 different functions
- Two opening windows and two closing windows
- Two user group windows
- Day-of-week, date-of-month, or holiday only schedules
- One holiday schedule of 366 days (leap year)

#### Programming

Installers can perform limited programming on-site with a keypad (critical parameters; such as account IDs, central station and RPS IP addresses and phone numbers, reporting formats, and more). They can also do full programming on-site or remotely (attended or unattended) with RPS. A programmable system passcode prevents unauthorized remote programming.

The following table shows the available languages for RPS

	<b>RPS programming</b>	RPS custom text*
English	<ul> <li></li> </ul>	•
Dutch		•
French		•
German		•
Hungarian		•
Italian		•
Portuguese		•
Spanish		•
Swedish		•

\* RPS custom text is text, that can be entered in RPS and which will then be displayed on keypads and on the mobile app.

#### Diagnostics

Keypads and RPS offer diagnostic help for monitoring and troubleshooting. The diagnostics features allow you to view the status of the wired and wireless devices. The features provide the status of the control panel and its connected devices, such as firmware version, power, and missing conditions. View the status of each area.

#### **3rd Party Integrations**

The control panel provides options for integration with software applications and solutions. Depending on the application, options include a Bosch SDK, RPS-API, Bosch proprietary MODE 2 or OPC interface. The OPC interface enables key DA (Data Access) and AE (Alarms & Events) to integrate with the Bosch BIS solution or 3rd party OPC Classic systems.

## **Bosch Video Management System integration**

With Bosch Video Management System (Bosch VMS) and an intrusion system, the VMS operator has a single user interface to monitor and control the intrusion system combined with video surveillance. With Bosch VMS and a control panel, the operator can, for example:

- View videos triggered by intrusion events, including all relevant information such as areas, point, and user show in the display with the event.
- View areas, points, outputs, and doors with their statuses on the Bosch VMS map, providing the exact location in the system.
- Turn on (arm) and turn off (disarm) areas.
- Bypass and unbypass points.

Requirements to integrate Bosch VMS with a control panel:

- A licensed Bosch VMS system using Professional Editions v5.5 or higher or Bosch VMS Enterprise.
- Edition v5.5 or higher.
- Expansion license to integrate the intrusion control panel. One license needed per control panel. Order number MBX-XINT-xx for the expansion license added to a Bosch VMS base license. Refer to the Bosch Video Management Software product page on the Bosch website, www.boschsecurity.com.
- Access to the control panel account and Remote Programming Software (RPS).

## **3rd Party Integrations**

The control panel provides options for integration with software applications and solutions. Depending on the application, options include a Bosch SDK, RPS-API, Bosch proprietary MODE 2 or OPC interface. The OPC interface enables key DA (Data Access) and AE (Alarms & Events) to integrate with the Bosch BIS solution or 3rd party OPC Classic systems.

#### **Bosch Security Manager Mobile App**

The Bosch Security Manager app allows users to control their security systems remotely from their smart devices. Users can:

- Easily view their system's status at a glance via the advanced and colorful design of the app
- Turn the security system On or Off (either the entire system or specific areas)
- Receive and filter event-driven push notifications
- View full event history for their system
- Add, edit, and delete users in their system
- Control outputs and doors
- View live video from Bosch IP cameras

• Access their panels from any device just by logging into the app with a Bosch ID (panels are now linked to an account and not a device)

Full functionality requires panel firmware 3.10 or higher and integration with the new Installer Services Portal. App users must have a valid email account and must be invited to the app by their Bosch certified dealer.

For those without access to the Installer Services Portal, Remote Security Control will remain available.

### Installer Services Portal (North America)

The Installer Services Portal offers secure and easy access for managing Bosch cloud and cellular communication services for remote programming and alarm reporting. The Bosch Cloud Remote Connect service eliminates the need to change local router settings, firewall rules or to use Domain Name Service (DNS). In addition to seamless integration with RPS for remote programming, the Remote Connect service fully supports the Bosch Security Manager mobile app.

#### UL2050 (SCIF) Support

The B3512 can be used in UL2050 SCIF applications. Validation numbers 4342 and 2332 can be found on the NIST Advanced Encryption Standard Algorithm Validation List.

### **Regulatory information**

Region	Region Regulatory compliance/quality marks				
USA	ANSI-SIA	CP-01-2010-Control Panel Standard - Fea- tures for False Alarm Reduction			
Europe	CE	EMC, LVD, RoHS [B6512, B5512, B4512, B3512]			
Brazil	ANATEL	04712-16-01855			
USA	CSFM	California State Fire Marshal			
	FCC	Part 15 Class B			
Canada	IC	ICES-003 - Information Technology Equip- ment (ITE)			
Australia	RCM	ACMA			
USA	UL	Underwriters Laboratories			
	UL	UL 365 - Police Station Connected Burglar Alarm Units			
	UL	UL 609 - Standard for Local Burglar Alarm Units and Systems			
	UL	UL 636 - Holdup Alarm Units and Systems			
	UL	UL 985 - Household Fire Warning System Units (6th edition)			

Region	Regulatory compliance/quality marks			
	UL	UL 1023 - Household Burglar Alarm System Units		
	UL	UL 1076 - Proprietary Burglar Alarm Units and Systems		
	UL	UL 1610 - Central Station Burglar Alarm Units		
	UL	UL 1635 - Standard for Digital Alarm Com- municator System Units		
Canada	ULC	Underwriters Laboratories of Canada S1871-20121210		
	ULC	CAN/ULC S303 - Local Burglar Alarm Units and Systems		
	ULC	CAN/ULC S304 - Standard for Signal Re- ceiving Center and Premise Burglar Alarm		
	ULC	CAN/ULC S545 - Residential Fire Warning System Control Units		
	ULC	CAN/ULC S559 - Fire Signal Receiving Centres and Systems		
	ULC	ULC-ORD C1023 - Household Burglar Alarm System Units		
	ULC	ULC-ORD C1076 - Proprietary Burglar Alarm Units and Systems		

## Installation/configuration notes

## (i) Notice

Not all products and features are available in all regions. Consult your local Bosch representative for availability details.

#### Keypads

B940W Touch screen KP, White (SDI2)

B942/B942W Touch Screen Keypad (SDI2)

B930 ATM Style Alphanumeric Keypad (SDI2)

B921C Two-line Capacitive Keypad (SDI2)

B920 Two-line Alphanumeric Keypad (SDI2)

B915/B915I Basic Keypad (SDI2)

#### Power

CX4010 Plug-in Transformer (18 VAC 22 VA 60 Hz)

ICP-TR1822-CAN Plug-in Transformer (110 VAC primary, 18 VAC 22 VA secondary)

DE-45-18 Transformer	Bosch conventional detectors, including Professional Series, Blue Line		
D126 Standby Battery (12 V, 7 Ah)	Gen2, Blue Line, Classic Line, Commercial Line, and Ceiling Mount motion detectors, as well as glass break, seismic, request-to-exit, photoelectric, heat, and smoke detectors.		
D1218 Battery (12 V, 18 Ah)			
D122 Dual Battery Harness	Modules		
D122 Dual Battery Harness with long leads	B201 2-wire Powered Loop Module		
Enclosures	B426 Conettix Ethernet Communication Module		
B10 Medium Control Panel Enclosure	B430 Plug-in Communicator, Telephone		
B11 Small Control Panel Enclosure	B440 Conettix Plug-in Cellular Communicators		
B12 Mounting Plate for D8103 Enclosure	B442 Conettix Plug-in Cellular Communicator (using GPRS)		
B8103 Universal Enclosure (requires a B12)	B443 Conettix Plug-in Cellular Communicator (using HSPA+)		
D8108A Attack Resistant Enclosure (requires a B12)	B444 Conettix Plug-in Cellular Communicator		
D8109 Fire Enclosure (requires a B12)	B444-A Plug-in cell module, AT&T LTE		
D8108A-CE Attack Resistant Enclosure with Built-in Transformer (requires	B444-V Plug-in cell module, Verizon LTE		
a B12)	B450 Conettix Plug-in Communicator Interface		
B-ENCL-1 Metal Enclosure Kit (includes B12 and transformer)	B520 Auxiliary Power Supply Module		
Accessories	B810 wireless receiver (RADION)		
B56 Keypad Surface Mount Box	B820 SDI2 Inovonics Interface Module		
B96 Keypad Trim Bezel	D113 Battery Lead Supervision Module		
B99 USB Direct Connect Cable	D125B Dual Class B Initiating Module		
B501-10 Interconnect wiring cables (pack of 10)	D129 Class A Initiating Module		
Detectors	D130 Auxiliary Relay Module		
FCC-380 Carbon Monoxide Detector	D132A Smoke Detector Reversing Relay Module		
F220-P: Photoelectric Smoke Detector	D134 Dual Relay Module		
F-220-PTH: Photoelectric/Heat Detector	D135A Low Battery Disconnect Module		
	D185 Reverse Polarity Signaling Module		
FCP-OT320 Multisensor Detector Optical/Thermal	D192G Class "B", Style Y Bell Circuit Supervision		
FCP-0320 Optical Smoke Detector	Applications		
FCH-T320 Heat Detector			

Remote Programming Software (RPS or RPS-LITE) v6.03 and higher Bosch Video Management System v5.5 and higher

## Remote Security Control

### **Conettix receivers**

(Managed and configured with Conettix D6200 Programming/Administration Software v2.00)

Conettix D6600 Communications Receiver/Gateway (with only D6641 line cards installed) with CPU version 01.10.00

 $\label{eq:conettix} Conettix\,D6100IPv6\ Communications\ Receiver/Gateway\ with\ CPU\ version\ 61.10.00$ 

Conettix D6100i Communications Receiver/Gateway with CPU version 61.10.00

## **RADION wireless from Bosch**

B810 wireless receiver (RADION)

RFBT-A/RFBT bill trap

RFDL-11-A/RFDL-11 TriTech motion detector

RFDW-RM-A/RFDW-RM recessed mount door/window contact

RFDW-SM-A/RFDW-SM surface mount door/window contact

RFGB-A/RFGB glass break detector

RFKF-A/RFKF two-button keyfob

RFKF-FBS-A/RFKF-FBS four-button keyfob

RFKF-TBS-A/RFKF-TBS two-button keyfob

RFPB-SB-A/ RFPB-SB single-button panic

RFPB-TB-A/RFPB-TB two-button panic

RFRP-A/RFRP repeater

**RFHT-A Wireless heat detector** 

RFSM2-A Wireless smoke detector

RFCO-A Wireless CO detector

RFPR-12-A/RFPR-12 PIR motion detector

RFPR-C12-A/RFPR-C12 PIR curtain motion detector

RFUN-A/RFUN universal transmitter

**Inovonics Wireless** 

B820 SDI2 Inovonics Interface Module

ENKIT-SDI2 SDI2 Inovonics Interface and Receiver Kit. Includes B820 and EN4200

EN1210 Universal Transmitter (Single-input)

EN1210EOL Universal Transmitter with EOL Resistor

EN1210W Door-Window Transmitter with Reed Switch

EN1215EOL Universal Transmitter with Wall Tamper, Reed Switch, and EOL Resistor

EN1223D Water-resistant Pendant Transmitter (Double-button)

EN1223S Water-resistant Pendant Transmitter (Single-button)

EN1224-ON Multiple-Condition Pendant Transmitter

EN1233D Necklace Pendant Transmitter (Double-button)

EN1233S Necklace Pendant Transmitter (Single-button)

EN1235D Beltclip Pendant Transmitter (Double-button)

EN1235DF Fixed-location Transmitter (Double-button)

EN1235S Beltclip Pendant Transmitter (Single-button)

EN1235SF Fixed-location Transmitter (Single-button)

EN1247 Glass-break Detector Transmitter

EN1249 Bill Trap Transmitter

EN1242 Smoke Detector Transmitter

EN1260 Wall Mount Motion Detector

EN1261HT High Traffic Motion Detector

EN1262 Motion Detector with Pet Immunity

EN1265 360° Ceiling Mount Motion Detector

EN4200 Serial Receiver

EN5040-T High Power Repeater with Transformer

Parts	includ	ed	

Quantity	Component		
1	Control panel		
1	Literature pack:		
	• UL Installation Guide		
	• ULC Installation Guide (English and French)		
	Owner's Manual		

condensing (%)

Operating relative humidity, non-

5% - 93%

Quantity	Component		Network
	<ul> <li>Release N</li> <li>SIA Quick</li> <li>Quick Installation</li> </ul>	Reference Guide	Ethernet type
1	Literature CD c	ontaining product literature	Ordering info
1	Wiring label for Hardware pack • Mounting		B3512 IP contr Supports up to area for intrusi Order number F.01U.323.783 F.01U.416.972
Technica	<ul> <li>1 kΩ EOL</li> <li>Battery w</li> <li>Four #6 x</li> </ul>	ires 3/4 in self threading screws	Accessories B520 Auxiliary Provides auxili modules. Order number F.01U.172.941
Capacity			B201 2-Wire P
Number of points		16	The module pr circuit. The mo smoke detecto
Number of areas		1	devices to the Order number F.01U.323.798
Number of eve	ents	512	B810 Wireless
Number of users		11	Receives RF sig repeaters, and
Number of on-	board outputs	3	For use with co Order number
Number of SK	EDs	1	F.01U.323.799
Number of cus	stom functions	1	Harness with c (in parallel) to
Electrical	L		Order number 4.998.800.378
Current consu	mption (mA)	125 mA – 155 mA	<b>D122L Dual ba</b> Harness with c
Maximum auxiliary output current (mA)		800 mA	(89 cm). Conn compatible cor Order number
Output curren	t (A)	1.30 A	4.998.140.606
Nominal voltage (VDC)		12 VDC	<b>D126 Battery,</b> A rechargeable
Input voltage (VDC)		16.50 VDC - 18 VDC	secondary pow functions. Order number
Environm	ental		4.998.125.825
Operating tem	perature (°C)	0 °C – 49 °C	D1218 Battery The D1218 is a two bolt-faster
Operating tem	perature (°F)	32 °F – 122 °F	auxiliary power
		544 0.004	Order number

10/100BASE-T

#### rmation

#### trol panel, 16 points

o 16 points, 3 on-board outputs, and 1 sion, residential fire. On-board Ethernet. B3512 | 3 F.01U.390.779

#### y power supply module, 2A 12V

iary power to 12 VDC devices or to SDI2

B520 |

#### owered Loop

rovides a single powered initiating device odule supports compatible 12 V 2-wire ors. It also supports connecting burglary control panel.

B201 |

#### R

#### s SDI2 bus interface

gnals from RADION transmitters, d glassbreaks. Operates at 433.42 MHz. ompatible SDI2 bus control panels. B810 |

### 9 F.01U.383.394

#### ttery harness

circuit breaker. Connects two batteries o a compatible control panel. D122 |

#### attery harness, long

circuit breaker and leads measuring 35 in. ects two batteries (in parallel) to a ntrol panel in a separate enclosure. D122L |

#### 12V 7Ah

e sealed lead-acid power supply used as a wer supply or in auxiliary or ancillary

Order number <b>D126  </b>	Asset Key	Vepos
4.998.125.825	<b>4011</b>	<b>6845</b>

#### y, 12V 18Ah

a 12 V 18 Ah sealed lead-acid battery with ned terminals. It is used for standby and er. It connects to a compatible control D122 or D122L Dual battery harness. Order number D1218 4.998.125.820

## CX4010 Transformer, plug-in, 18V 22VA

For use in North America. 110 VAC primary voltage input. 18 VAC, 22 VA secondary input. Order number **CX4010** | **F.01U.020.504** 

# ICP-TR1822-CAN Transformer, plug-in, 18V 22VA, Canada

For use in Canada. 110 VAC primary voltage input. 18 VAC, 22 VA secondary input. Order number **ICP-TR1822-CAN** | **F.01U.005.574** 

## D8004 Transformer enclosure kit, grey

For applications that might require a remote transformer in an enclosure. Can be used with B Series control panels and D9412GV4/D7412GV4 control panels.

Order number **D8004** | 4.998.140.404

4.998.140.404

## B8103 Universal enclosure, white

White steel enclosure measuring 41 cm x 41 cm x 9 cm (16 in. x 16 in. x 3.5 in.).

Order number **B8103** 

F.01U.300.149

# D8108A Attack resistant enclosure, large

Grey steel enclosure measuring 41.5 cm x 41.5 cm x 9 cm (16 in. x 16 in. x 3.5 in.). UL Listed. Includes a lock and key set. Order number **D8108A | 4.998.125.920** 

## D8109 Fire enclosure, 16x16x3.5", red

Red enclosure, 16in. x 16in. x 3.5in. (41cm x 41cm x 9cm), 16 gauge (1.5mm) cold-rolled steel, full-length hinge, D101F lock and 2 D102F keys, UL Listed for commercial fire/burglary applications. Order number **D8109** | 4.998.800.205

#### B10 Steel enclosure, medium, white

White, steel enclosure. Accepts an optional lock and tamper switch. Measures 35.6 cm x 31.8 cm x 7.6 cm (14 in x 12.5 in x 3 in). Order number **B10** | **F.01U.268.495** 

#### F.010.268.495

## B11 Steel enclosure, small, white

White, steel enclosure. Accepts an optional lock and tamper switch. Measures 27.8 cm x 25.9 cm x 8.32 cm (10.9 in x 10.2 in x 3.3 in). Order number **B11** 

F.01U.262.005

## B12 Mounting plate for D8103 enclosure

Required for mounting select control panels and other devices in B8103, D8103, D8108A, D8109, and BATB Battery Box enclosures. Order number **B12** 

#### F.01U.260.846

B-ENCL-1 Metal Enclosure kit w/transformer

White steel enclosure with installed 220 VAC transformer. Order number **B-ENCL-1** 

F.01U.322.491

#### D101 Enclosure lock and key set

Short-body lock set with one key supplied. Uses the D102 (#1358) replacement key. Order number **D101 | 4.998.800.200** 

#### D110 Tamper switch for enclosure, 2pcs

Screw-on tamper switch that fits all enclosures. Shipped in packages of two. Order number **D110** | **4.998.137.947 F.01U.246.707** 

#### **ICP-EZTS Dual tamper switch**

Combination tamper switch with a wire loop for additional tamper outputs. Order number **ICP-EZTS** | **F.01U.217.038** 

#### B99 USB direct connect cable

Male A to Male A USB cable for local programming of control panels with on-board USB ports. Order number **B99** 

## F.01U.278.853

#### **B915 Basic Keypad**

Two-line alphanumeric basic keypad with language function keys.

Available languages: English, Chinese, Dutch, French, German, Greek, Italian, Hungarian, Polish, Portuguese, Spanish, Swedish.

# Order number **B915** | F.01U.323.784 F.01U.385.667

## B915I LCD keypad, icon keys, SDI2

Two-line alphanumeric basic keypad with icon function keys.

Available languages: English, Chinese, Dutch, French, German, Greek, Italian, Hungarian, Polish, Portuguese, Spanish, Swedish.

Order number **B915I |** F.01U.385.666 F.01U.315.437

#### B920 2 Line Alpha Numeric Keypad (SDI2)

Two-line alphanumeric keypad

Available languages: English, Dutch, French, German, Hungarian, Italian, Portuguese, Spanish, Swedish. Order number **B920 |** 

## F.01U.323.785 F.01U.385.668

## B921C Two-line Keypad w/Touch keys, Inputs

Two-line alphanumeric keypad with inputs and capacitive touch keys in black. Available languages: English, Dutch, French, German, Hungarian, Italian, Portuguese, Spanish, Swedish. Order number **B921C** | **F.01U.323.786 F.01U.385.734** 

#### B930 ATM Style-Alpha Numeric Keypad (SD12)

Five-line ATM style alphanumeric keypad Available languages: English, Dutch, French, German, Hungarian, Italian, Portuguese, Spanish, Swedish. Order number **B930** | **F.01U.323.787 F.01U.385.669** 

## **B940W Slim Touch Keypad**

SDI2 compatible touch screen keypad with function keys.

Available languages: English, Chinese, Dutch, French, German, Greek, Italian, Hungarian, Polish, Portuguese, Spanish, Swedish.

#### Order number B940W | F.01U.358.360

## B942 Touch Screen KP Prox/Input/Output, black

Black SDI2 touch screen keypad with inputs and one output.

Available languages: English, Chinese, Dutch, French, German, Greek, Italian, Hungarian, Polish, Portuguese, Spanish, Swedish.

Order number **B942** F.01U.323.788

# B942W Touch screen KP, prox/input/output, white

White SDI2 touch screen keypad with inputs and one output.

Available languages: English, Chinese, Dutch, French, German, Greek, Italian, Hungarian, Polish, Portuguese, Spanish, Swedish.

Order number B942W |

## F.01U.323.789

#### **B426 Ethernet Communication Module**

Supports two-way communications over Ethernet networks for compatible control panels

Order number <b>B426</b>	Asset Key	Vepos
F.01U.324.383 F.01U.414.222	4235	7897

## B442 Plug-in cellular module, GPRS

Multi-function cellular communicator that provides IP communication over a (GPRS) cellular network Order number **B442** Asset Kev Vonos

	ASSUREY	vepus
F.01U.283.090 F.01U.385.514	4235	8330

## B443 Plug-in Cellular, HSPA+ (3G+)

Multi-function 3G/4G cellular communicator providing IP communication over a GPRS/EDGE/UMTS/HSPA+ cellular network Asset Kev Vepos

Order number B443 | F.01U.323.796 F.01U.385.515

#### B444 Plug-in cellular module, VZW LTE, hot

Pre-activated 4G LTE cellular communicator for secure two-way IP communication on the Verizon Wireless LTE network.

4235

8336

Order number **B444** F.01U.335.089

## B444-C Plug-in cell module, VZW LTE, cold

Non-activated 4G LTE cellular communicator for secure two-way IP communication on the Verizon Wireless LTE network.

Order number B444-C | F.01U.349.007

#### Represented by:

Europe, Middle East, Africa: Bosch Security Systems B.V. P.O. Box 80002 5600 JB Eindhoven, The Netherlands Phone: + 31 40 2577 284 www.boschsecurity.com/xc/en/contact/ www.boschsecurity.com

Germany: Bosch Sicherheitssysteme GmbH Robert-Bosch-Ring 5 85630 Grasbrunn Tel.: +49 (0)89 6290 0 Fax:+49 (0)89 6290 1020 de.securitysystems@bosch.com www.boschsecurity.com

# North America

Bosch Security Systems, LLC 130 Perinton Parkway Fairport, New York, 14450, USA Phone: +1 800 289 0096 Fax: +1 585 223 9180 onlinehelp@us.bosch.com www.boschsecurity.com

#### Asia-Pacific:

Robert Bosch (SEA) Pte Ltd, Security Systems 11 Bishan Street 21 Singapore 573943 Phone: +65 6571 2808 Fax: +65 6571 2699 www.boschsecurity.com/xc/en/contact/ www.boschsecurity.com

#### B444-A Plug-in cell module, AMEC LTE

This communication module provides secure two-way IP communication on North American wireless networks. Only available in Canada. Order number B444-A F.01U.374.184 F.01U.385.518

#### B444-V Plug-in cell module, VZW LTE

This communication module provides secure two-way IP communication on the Verizon Wireless network. Order number B444-V | F.01U.374.183 F.01U.385.517

## Software Options D5500CU Upgrade DVD

RPS software is available for free download on the RPS product page. It is also available on DVD-ROM. Order number D5500CU | 4.998.143.725

#### Services

## EWE-CTRCOM-IW 12 mths wrty ext Control Communicator 12 months warranty extension

Order number EWE-CTRCOM-

IW |