LBB 451x/00 Integrus Radiators

www.boschsecurity.com





These radiators are used to distribute infrared signals throughout the conference venue, enabling delegates to listen to the proceedings by means of personal pocket receivers.

Functions

- Universal mains power facility allows use worldwide
- No fan cooled by convection resulting in quieter operation and less moving parts to wear out
- LED indicators for radiator status checking
- Communication between radiator and transmitter for easy checking by the operator
- Automatically switches on when transmitter is switched on and vice versa
- Automatic cable equalization ensures maximum transmission efficiency with different quality of cables
- Automatic cable termination simplifies installation
- Temperature protection circuitry automatically switches radiator from full- to half- power if the temperature becomes too high
- Adjustable radiator angle ensures maximum coverage
- IREDs protected by a cover plate, making the units easy to maintain and clean
- · Attractive and stylish design

Controls and Indicators

Safety eye

standard quality channels)

standard quality channels)

• Two yellow LEDs: one on each radiator panel to indicate that this panel is switched on and is receiving carrier waves from the transmitter

▶ LBB 4511/00 covers up to 1300 m² (one carrier, 4

▶ LBB 4512/00 covers up to 2600 m² (one carrier, 4

 Automatic gain control ensures the IREDs (infrared emitting diodes) function with maximum efficiency
Power output selection for efficiency and economy

- Two red LEDs: one on each radiator panel to indicate that this panel is in standby mode
- Red and yellow LEDs simultaneously illuminated to indicate the radiator panel is malfunctioning
- Red LED flashing and yellow LEDs to indicate the radiator panel is in temperature protection mode
- Power reduction switch to reduce the output of the radiator to half-power
- Two delay compensation switches to compensate for differences in cable lengths between transmitter and radiators

Interconnection

- Male Euro socket for mains connection
- HF input and output connectors (2 x BNC) for connection to transmitter and loop-through to other radiators

Parts included

Quantity	Component
1	LBB 451x/00 Integrus Radiator
1	Mains cable

1	Bracket for mounting unit on ceiling
---	--------------------------------------

2 Plates for mounting unit on floor stand

Technical specifications

Electrical

Radiator angle

Weight

Color

floor-stand mounting

wall/ceiling mounting

LBB 4511 without bracket

LBB 4512 without bracket

LBB 4511 with bracket

LBB 4512 with bracket

Mains voltage	100-240 Vac, 50-60 Hz
Power consumption	
LBB 4511, operating	100 W
LBB 4511, standby	8 W
LBB 4512, operating	180 W
LBB 4512, standby	10 W
Number of IREDs	
LBB 4511	260
LBB 4512	480
Total optical peak intensity	
LBB 4511	12 W/sr
LBB 4512	24 W/sr
Angle of half intensity	± 22°
HF input	nominal 1 Vpp, minimum 10 mVpp
Mechanical	
Mounting	Suspension bracket for direct ceiling mounting Mounting plates for floor stands with M10 and 1/2 in Whitworth thread Optional wall mounting bracket (LBB 3414/00) available
Dimensions (H x W x D)	
LBB 4511 without bracket	200 x 500 x 175 mm (7.9 x 19.7 x 6.9 in)
LBB 4512 without bracket	300 x 500 x 175 mm

(11.0 x 19.7 x 6.9 in)

0, 15, 30, 45, 60, 75 and 90°

0, 15, and 30°

6.8 kg (15 lb)

7.6 kg (17 lb)

9.5 kg (21 lb)

10.3 kg (23 lb)

bronze

Ordering information

LBB 4511/00 Integrus Radiator

Integrus medium-power radiator to cover up to 1300 m² (13993 ft²). Order number **LBB4511/00**

LBB 4512/00 Integrus Radiator

Integrus high-power radiator to cover up to 2600 m² (27986 ft²). Order number **LBB4512/00**

LBB 4511/00-US Integrus Radiator (US) Integrus medium-power radiator to cover up to 1300 m² (13993 ft²). US version. Order number LBB4511/00-US

LBB 4512/00-US Integrus Radiator (US)

Integrus high-power radiator to cover up to 2600 m2 (27986 ft2). US version. Order number LBB4512/00-US

Accessories

LBB 3414/00 Wall Mounting Bracket LBB 3414/00 Wall Mounting Bracket for radiators.

Order number LBB3414/00

INT-FCRAD Flight Case for Radiator

INT-FCRAD Flight Case for 1 radiator. Order number INT-FCRAD

Represented by:

Americas:

Americas: Bosch Security Systems, Inc. 12000 Portland Avenue South Burnsville MN 55337, USA Phone: +1-800-392-3497 Fax: +1-800-955-6831 audiosupport@us.bosch.com www.boschsecurity.com

Europe, Middle East, Africa: Bosch Security Systems B.V. P.O. Box 80002

P.O. Box 80002 5617 BA Eindhoven, The Netherlands Phone: + 31 40 2577 284 Fax: +31 40 2577 330 emea.securitysystems@bosch.com www.boschsecurity.com

@ Bosch Security Systems 2013 | Data subject to change without notice 1844494603 | en, V6, 01. Nov 2013

Asia-Pacific:

Asia-Pacific: Robert Bosch (SEA) Pte Ltd, Security Systems 11 Bishan Street 21 Singapore 573943 Phone: +65 6571 2808 Fax: +65 6571 2609 apr.securitysystems@bosch.com www.boschsecurity.asia

China:

China: Bosch (Shanghai) Security Systems Ltd. 201 Building, No. 333 Fuquan Road North IBP Changning District, Shanghai 200335 China Phone +86 21 22181111 Fax: +86 21 22182398 www.bacsbecurity.com.cn www.boschsecurity.com.cn

America Latina:

America Latina: Robert Bosch Ltda Security Systems Division Via Anhanguera, Km 98 CEP 13065-900 Campinas, Sao Paulo, Brazil Phone: +55 19 2103 2860 Fax: +55 19 2103 2862 Iatam.boschsecurity@bosch.com www.boschsecurity.com