

INT-TXO Transmitter OMNEO

INTEGRUS



The INT-TXO is the central element in the INTEGRUS system that allows INTEGRUS to interact with the DICENTIS Conference System. The INT-TXO modulates the signals into carrier waves and transmits them to the radiators in the room.

When connected to a DICENTIS system, the Transmitter OMNEO is fully controlled by DICENTIS and does not require any configuration.

Functions

- The Transmitter OMNEO can be connected to, and controlled by, a DICENTIS system. In this setup, it can also be powered through a DICENTIS cable, including the RSTP functionality
- The INT-TXO can be switched to the slave mode to act as a repeater of another INT-TXO. In this case, the signal is received through the coaxial input and synchronizes with the master INT-TXO. The slave mode is enabled through a switch on the rear of the device

Controls and indicators

- System and radiator status visible at the front of the device
- Two LEDs are located near each Ethernet connector

Interconnections

- Different power options that do not influence each other:
 - DC wall adapter
 - DICENTIS
 - PoE

- ▶ Fully integrated with the DICENTIS Conference System, no configuration required
- ▶ Excellent audio quality
- ▶ 4 channels out of the box
- ▶ Up to 28 licenses can be added to the INT-TXO for a total of 31 languages and 1 floor
- ▶ Infrared allows freedom of movement for participants

- One BNC connector for accepting a HF signal from another transmitter. The INT-TXO includes a switch to set the transmitter as a slave to another transmitter with synchronized audio
- Six BNC connectors for output of HF signal to up to 30 radiators
- Power through the DICENTIS system cables
- Two DICENTIS connectors compatible with RJ45 connectors for:
 - Loop through in a DICENTIS system, including RSTP
 - Powering through PoE.

Parts included

Quantity	Component
1	INT-TXO Transmitter OMNEO
1	DC wall adapter

Technical specifications

Electrical

Power consumption (W)	10 W
Nominal voltage (VDC)	48 VDC
PoE input	PoE IEEE 802.3af Type 1, Class 3; PoE IEEE 802.3at Type 1, Class 3
Battery type	Lithium

Typical battery life (years)	7
------------------------------	---

Mechanical

Mounting type	Rack-mounted; Tabletop
Dimensions (H x W x D) (mm)	44.45 mm x 442 mm x 390 mm
Dimensions (H x W x D) (in)	1.75 in x 17.40 in x 15.35 in
Color in RAL	RAL 9017 Traffic black

Environmental

Operating temperature (°C)	5 °C – 45 °C
Operating temperature (°F)	41 °F – 113 °F
Storage temperature (°C)	5 °C – 45 °C
Storage temperature (°F)	41 °F – 113 °F
Transportation temperature (°C)	-30 °C – 70 °C
Transportation temperature (°F)	-22 °F – 158 °F
Operating relative humidity, non-condensing (%)	5% – 95%

Ordering information

INT-TXO Transmitter OMNEO

Integrus 4-channel transmitter.

Order number **INT-TXO | F.01U.351.763**

Software Options

INT-L1AL 1 Additional language license

License to add one language channel to INT-TXO.

Order number **INT-L1AL | F.01U.406.605**

Services

EWE-INTTXO-IW 12 mths wrty ext Transmitter OMNEO

12 months warranty extension

Order number **EWE-INTTXO-IW | F.01U.406.935**

Represented by:

Europe, Middle East, Africa:
Bosch Security Systems B.V.
P.O. Box 80002
5600 JB Eindhoven, The Netherlands
Phone: + 31 40 2577 284
www.boschsecurity.com/xc/en/contact/
www.boschsecurity.com

Germany:
Bosch Sicherheitssysteme GmbH
Robert-Bosch-Ring 5
85630 Grasbrunn
Tel.: +49 (0)89 6290 0
Fax: +49 (0)89 6290 1020
de.securitysystems@bosch.com
www.boschsecurity.com

North America:
Bosch Security Systems, LLC
130 Perinton Parkway
Fairport, New York, 14450, USA
Phone: +1 800 289 0096
Fax: +1 585 223 9180
onlinehelp@us.bosch.com
www.boschsecurity.com

Asia-Pacific:
Robert Bosch (SEA) Pte Ltd, Security Systems
11 Bishan Street 21
Singapore 573943
Phone: +65 6571 2808
Fax: +65 6571 2699
www.boschsecurity.com/xc/en/contact/
www.boschsecurity.com